





YEMA NAVYGRAF MARINE NATIONALE QUARTZ WATCHES



B



POSITION B TIME SETTING

In order to adjust the time, unscrew the crown to the last notch. Then turn it in either direction until the hands indicate the correct time.

MAINTENANCE
OF YOUR YEMA WATCH

A YEMA watch requires little maintenance. However, some precautions must be taken to ensure the durability of your YEMA:

- Ensure that the crown is perfectly screwed down after winding up the movement and/or setting the time and the date. Once the crown is fully screwed down against the case, your YEMA watch is guaranteed waterproof.
- Avoid activities that may expose your watch movement to shocks.
- Never use chemicals to clean your YEMA watch. Use a microfibre cloth and wash the metal, rubber, fabric bracelets and waterproof cases from time to time with a soft brush and soapy water. We recommend that you do not use abrasive or corrosive products (solvents, detergents, perfume, etc.).
- Always rinse your watch with fresh water after it's been exposed to salt water.

CALIBER : RONDA 503 FE

MODELS :

YEMA NAVYGRAF MARINE NATIONALE QUARTZ - YMHFMN39-GM

YEMA.COM

YEMA WATCHES reserves the right to modify the models illustrated in this publication at any time.